

HY-OPTIMA™ 700B Series

General Use Inline Hydrogen Process Analyzer

Applications

The HY-OPTIMA™ 700B Series inline hydrogen process analyzer is ideal for gas streams where real-time, hydrogen-specific measurements can enhance process plant efficiencies, improve yields, and reduce maintenance costs:

Fuel Cells

H₂ measurement on both anode and cathode side

Natural Gas

H₂ in natural gas or biomethane

Industrial Gas Supply and Hydrogen Production

- Air separation
- Steam methane reforming
- Electrolysis process streams

Laboratory

- Research applications

Manufacturing

- Metals annealing
- Semiconductors
- Oil hydrogenation

Advantages

- Highly reliable
- Low life cycle cost
- Easy to install and operate
- Minimal maintenance required
- No cross sensitivity to combustible gases
- Real time, continuous hydrogen measurement
- Tolerant of many harsh background contaminants
- No reference or carrier gases required
- Non-consumable solid state technology
- Field-configurable settings





The HY-OPTIMA™ 700B Series analyzer provides the most accurate, tolerant and affordable hydrogen process gas measurement solution for industrial markets. The general use analyzer uses a solid-state, non-consumable sensor for direct hydrogen measurement in process gas streams, with no cross sensitivity to other gases.

How it Works A thin film palladium-nickel alloy absorbs and desorbs hydrogen as it comes in contact with the sensor. The palladium catalyzes the hydrogen molecule into atomic hydrogen, which gets absorbed into the metal lattice and changes the bulk resistivity. This change in resistance is calculated very accurately and reported in real time. The analyzer is hydrogen specific because even though palladium can catalyze several elements, only hydrogen can penetrate the lattice structure at a rate that is meaningful to the measurement. As a result it is unaffected by any other gases. Proprietary coatings protect the sensor to enable continuous operation in environments with high levels of CO and H₂S. Since it is a solid state device, the sensor does not degrade over time. The output reports the partial pressure of the hydrogen in the process stream, which varies linearly with changes in pressure.

Ease of Use With no moving parts, the analyzer is extremely reliable and easy to use. Once installed and field calibrated, it typically only requires a quick calibration every three months, using readily available primary standard gases that span the expected operating range. No other maintenance is necessary. Communication with the unit is either via an analog 4-20mA output or serial communication using RS232 or RS422.

Performance and Safety The model 710B, 730B, and 740B analyzers are intended for use in dry gas streams where hydrogen is always present, and can be safely exposed to hydrogen continuously. The model 720B is designed for processes where hydrogen is only occasionally present for short periods, as may occur if there is a leak or an upset condition. For optimal performance, a conditioning system is available from H2scan and strongly recommended to ensure that the pressure at the analyzer is between 0.95 to 1.1 atm and the gas temperature does not exceed 60°C. The 700B series analyzers are UL and CE approved for safe general use operation.

HY-OPTIMA 700B Series Specifications

Performance

Operating Pressure at Analyzer

Recommended: 0.95 – 1.1 atm absolute (14.0 – 16.1 psia)

Maximum: 2 atm absolute (29.4 psia)

Note: Analyzers are factory calibrated at 1 atm. For operation at higher pressure special factory calibration may be required.

Process Gas Temperature

-20 to 60°C

Flow Rate

0.1 to 10 slpm

Operating Humidity: < 95% RH (non-condensing)

Calibration Interval: 90 days

Output Signals

Analog: 4-20 mA

Serial: RS232 or RS422

Relays: 1A / 30 VDC SPDT

Two programmable relays with both NO and NC contacts, and one programmable relay with NC contact only

Power

Input Voltage

10 – 26 VDC

Input Power

10 W

Physical

Dimensions

9.3in (L) x 3.4in (W) x 1.4in (D)

Weight

0.8 lbs (0.4 kg)

Adapter Fitting: ½ in MNPT

Environmental

Operating temp: -20 to 55°C

Storage temp: -40 to 80°C

Safety Certifications



Product Selection

MODEL	Hydrogen Range		Hydrogen MUST be present	CO Limit	H ₂ S Limit	T90 Response Time (sec)	Accuracy		Drift/Week		Repeatability		Linearity		Calibration Background Gas
	Low	High					Low to 10% H ₂	10 to 100% H ₂	Low to 10% H ₂	10 to 100% H ₂	Low to 10% H ₂	10 to 100% H ₂	Low to 10% H ₂	10 to 100% H ₂	
710B	0.1%	10%	Yes	<100 ppm	<20 ppm	< 90	0.15%	N/A	0.15%	N/A	0.15%	N/A	0.15%	N/A	N ₂
730B	0.5%	100%	Yes	<100 ppm	<1000 ppm	< 60	0.3%	1.0%	0.2%	0.4%	0.2%	0.4%	0.2%	0.4%	N ₂
740B	0.5%	100%	Yes	20%	3%	< 90	0.3%	1.0%	0.2%	0.4%	0.2%	0.4%	0.2%	0.4%	N ₂
720B	0.4%	5%	No	0	0	< 60	0.3%	N/A	0.3%	N/A	0.3%	N/A	0.3%	N/A	O ₂ , N ₂

Note: Sensor performance specifications are absolute and assume a dry process stream, an ambient temperature of 25°C, constant pressure, and are in addition to any errors in the calibration gases used.